

LS OIL PUMP INSTALLATION  
INSTRUCTIONS FOR #LS/AL/TL

CAUTION: LS OIL PUMPS MUST  
BE ACCURATELY CENTERED  
TO CRANK CENTER LINE.

---

